



TIME
parts

FOR US, YOUR TIME IS PRECIOUS

A company that understands how your time is precious!

Time Parts is a company with 20 years of experience in the production of polyurethane bushings for trucks, buses, and utility vehicles. Specialized in this sector, the company has become a global reference in manufacturing high-quality and durable parts.

The polyurethane bushings produced by Time Parts are designed to meet the specific needs of vehicles, offering an efficient solution to improve suspension and reduce wear on other vehicle components, saving tires and fuel. Polyurethane is a resilient and flexible material capable of absorbing the impacts produced by the harsh road conditions, ensuring greater comfort and stability during driving.

The company invests in cutting-edge technology and manufacturing processes to ensure the precision and quality of its parts. In addition, Time Parts uses high-quality raw materials and conducts rigorous tests on its products, guaranteeing the durability and reliability of the parts.

With a team of experienced and dedicated professionals, the company constantly seeks to enhance its products and offer innovative solutions to the parts market. Time Parts also values customer service, striving to understand their needs, providing technical support, and offering a warranty.



REAL SOLUTION, MULTIPLE BENEFITS



Polyurethane (PU)

Resistant to oils, greases, solvents, and saltwater;

Greater savings on tires, suspension frame, and fuel;

Advanced technology and design aimed at facilitating maintenance and replacement with split bushings;

Absorbs impacts and vibrations, providing greater comfort and safe driving;

Low noise level.



Rubber

Degrades when in contact with oils, greases, and solvents;

Premature wear on tires, suspension frame, and increased fuel consumption;

Difficult and exhaustive maintenance for mechanics. Have you ever tried replacing a leaf spring bushing?

Premature clearance, with less control, stability, and maneuverability;

Makes noise during the journey.



Mercedes-Benz

NC 0010



384 320 7050

MBB STABILIZER
BAR BUSHING
OF 1417 / 1620 / 1721

NC 0011



008 323 0053

FRONT LOWER SHOCK
BSORBER BUSHING
WITH SPACER
OF 1417 / 1620 / 1721

NC 0012



008 323 0150

FRONT UPPER SHOCK
ABSORBER BUSHING
OF 1417 / 1620 / 1721

NC 0019



970 168 4050

GEARSHIFT LEVER LINKAGE
BUSHING
OF 1417 / OF 1722

NC 0016



667 324 0253

SPRING BUSHING
SPACER 12MM HOLE
LO 709 / 912 / 814 / 914

NC 0018



667 332 0050

SPRING BUSHING SPACER
18MM HOLE
LO 709 / 912 / 814 / 914

NC 0039



000 323 0685

FRONT AND REAR SHOCK
ABSORBER BUSHING
LO 709 / 912 / 814 / 914

NC 0031



634 320 0077

REAR SPRING STOP
MBB 1724
OF 1724

NC 0039A



000 323 6950

FRONT AND REAR SHOCK
ABSORBER BUSHING
WITH SPACER
LO 709 / 912 / 814 / 914

NC 0052



670 320 0444

FRONT / REAR SPRING
BUSHING AND SHACKLE
48/30MM
LO 709 / 912 / 814 / 914

NC 0052A



670 320 0444

FRONT / REAR SPRING
BUSHING AND SHACKLE
48/12MM
LO 709 / 912 / 814 / 914

NC 0052B



670 320 0444

FRONT / REAR SPRING
BUSHING AND SHACKLE
48/18MM
LO 709 / 912 / 814 / 914

NC 0053



319 324 0750

FRONT / REAR SPRING
BUSHING AND SHACKLE
608 / 608D

NC 0053A



318 322 0250

UPPER FRONT SPRING
SHACKLE BUSHING
LO 709 / 912 / 814 / 914

NC 0054



314 326 0481

MBB STABILIZER
BAR BUSHING
608 / 608D

NC 0055



688 320 0044

REAR SPRING BUSHING
FOR FRONT 36MM HOLE
LO 709 / 912 / 814 / 914

NC 0055A



979 320 0544

REAR SPRING BUSHING
FOR FRONT 18MM THICK
BODY **LO 916**

NC 0056



688 320 7173

MBB STABILIZER
BAR BUSHING
LO 709 / 912 / 814 / 914

NC 0055B



979 320 0544

REAR SPRING BUSHING FOR
FRONT 18MM THIN BODY
LO 916

NC 0026



611 324 0355

SPRINTER REAR SPRING
BUSHING 16MM HOLE
SPRINTER



NC 0027



000 321 0250

SPRINTER REAR SPRING
BUSHING 16MM HOLE
SPRINTER



NC 0118A



634 326 0081

REAR STABILIZER BAR
BUSHING BRACKET
O500U

NC 0117



384 323 7081

FRONT STABILIZER BAR
BUSHING BRACKET
1417 / 1418 / 1721 / 1722

NC 0118



301 326 0081

REAR STABILIZER BAR
BUSHING BRACKET
O500U

NC 0122



000 326 1350

REAR SHOCK ABSORBER
BUSHING
OF 1417 / OF 1620 / OF 1721

NC 0128



667 322 0650

FRONT/REAR SPRING
SUPPORT BUSHING PART
REAR **912 / 914**

NC 0129



DOOR BUSHING
BRACKET

NC 0170B



958 320 0040

REAR STABILIZER
BAR SLEEVE 36MM
ACELLO / ATEGO

NC 0170



979 320 0444

FRONT STABILIZER BAR
SLEEVE 32.5MM
ACELLO / ATEGO / 916

NC 0170A



979 320 0344

REAR STABILIZER BAR
SLEEVE 26.5 MM
ACELLO / ATEGO

NC 0140



384 324 7008

FRONT SPRING STOP
**OF 1417 / 1418 /
1721 / 1722**

NC 0140P



384 324 7008

SMALL FRONT SPRING STOP
OF 1417 / 1418 / 1721 / 1722

NC 0144



000 323 3544

PAIR OF NEEDLE SUSPENSION
AIR SHOCK ABSORBER BUSHING
O500 / O500U / 1725 / 1826

NC 0153



307 323 0044

PAIR OF UPPER / LOWER
FRONT SHOCK ABSORBER
NEEDLE BUSHING
O500 / O500U / 1725 / 1826

NC 0154



000 153 0681

ELECTRONIC MODULE
SUPPORT BUSHING - PLD
915 / 1722

NC 0162



317 326 0068

NEEDLE REAR AXLE SPRING
SHOCK ABSORBER BUSHING
0370 / 0371 / 0400

NC 0177



318 320 0073

FRONT / REAR STABILIZER
BAR EYELET BUSHING
ACELLO / ATEGO

NC 0182



941 326 0050

MBB REAR STABILIZER
BAR SLEEVE
OF 1724

NC 0205



000 320 0744

SLEEVE **1823 / 1823L**
1823LS / 1828A / 1831L
1831LS

NC 0028A



A - 974 327 0181

FRONT STABILIZER BAR
EYELET BUSHING
OF 1724L - 1721L

NC 0210



A - 3683300011

MERCEDES FRONT REACTION
BAR EYELET BUSHING
**OF 1721L / OF 1724L /
OH 1621L**

NC 0181



979 327 0287

MBB REAR STABILIZER BAR
SLEEVE
OF 1724L / 1721L





NC 0028



2V5 505 174

REAR STABILIZER BAR
EYELET BUSHING
MAN 18.280 / TGX

NC 0029



2Z0 511 423C

REAR STABILIZER BAR
SLEEVE BRACKET
MAN 18.280 / TGX

NC 0032



22B 411 041

FRONT STABILIZER BAR
SLEEVE BRACKET
MAN 18.280 / TGX

NC 0038



600 511 413A

VW REAR STABILIZER
BAR SLEEVE 30MM
8140 / 9150

NC 0039



T06 513 441

FRONT SHOCK ABSORBER
BUSHING
7100 / 8120 / 8140 / 9150

NC 0040



600 511 421

VW REAR STABILIZER BAR
BUSHING
7100 / 8120 / 8150 / 9150

NC 0041



2RD 513 481

REAR SHOCK ABSORBER
BUSHING
7100 / 8120 / 8140 / 9150

NC 0042



T2D 411 171

FRONT VW SPRING
BUSHING
6.90 ATÉ 13.130

NC 0043



2RE 511 181

REAR VW SPRING
BUSHING
8120 / 8140 / 8150 / 9150

NC 0044



TJG 413 435

FRONT AND REAR SHOCK
ABSORBER BUSHING
**16180 / 16210 / 17210 /
17240**

NC 0045



TAP 599 191

REAR SPRING SUPPORT
BUSHING ADAPTED
6.90.7100

NC 0048



T06 411 045

FRONT STABILIZER BAR
EYELET BUSHING
7100 / 8120 / 8140 / 9150

NC 0202



2115 133 811

KOMBI SHOCK ABSORBER
BUSHING
KOMBI

NC 0068



TAR 411 283A

SQUARE ANTI-NOISE PAD
8120 / 8140.8150 / 9150

NC 0071



T11 511 181

FRONT VW SPRING BUSHING
14120 ATÉ 16220

NC 0079



T21 411 045

FRONT STABILIZER BAR
BUSHING **16180 / 16210 /
17210 / 17240**

NC 0079A



22B 411 045C

FRONT STABILIZER BAR
EYELET BUSHING
MAN 18.280

NC 0094A



2SL 411 071

FEMALE FRONT STABILIZER
BAR LINK BUSHING **16180 /
16210 / 17210 / 17240**

NC 0094B



2SL 411 071A

MALE FRONT STABILIZER
BAR LINK BUSHING **16180 /
16210 / 17210 / 17240**

NC 0094



2SL 411 071

FRONT STABILIZER BAR LINK
BUSHING KIT **16180 / 16210 /
17210 / 17240**

NC 0135



2W0 411 041A

FRONT STABILIZER BAR SLEEVE
35MM **15180 / 15190 / 17210 /
17230**

NC 0138



2VD 411 041

FRONT STABILIZER BAR
SLEEVE 35MM
8120 / 8150 / 8150E / 9150E

NC 0120



TAR 411 041

FRONT STABILIZER BAR
SLEEVE **16180 / 16210 /
17210 / 17240**

NC 0120A



2T2 411 041

FRONT STABILIZER BAR
SLEEVE 38MM **13190 /
15190 WORKER**

NC 0121



TJG 511 413

REAR STABILIZER BAR
SLEEVE **16180 / 16210 /
17210 / 17240**

NC 0033



2T2 411 041

FRONT STABILIZER BAR
BUSHING **MAN 15.180
15.190 17.230**

NC 0207



2T2 411 041

UPPER AND LOWER FRONT
SHOCK ABSORBER BUSHING
MAN 18.280

NC 0213



2Z0 511 423

REAR STABILIZER BAR
BUSHING **17240 OT /
18310 OT**





NC 0044



1 134 962

VOLVO FRONT AND REAR SHOCK ABSORBER BUSHING
B58 / N10 / N12

NC 0147



20 587 455

LOWER REAR STABILIZER BAR SLEEVE 50MM HOLE
B270F / B290F / VM270

NC 0149



20 542 833

UPPER REAR STABILIZER BAR SLEEVE 38MM HOLE
B270F / B290F / VM270

NC 0152



205 530 83

FRONT SPRING EYELET BUSHING 16MM HOLE
M240 / VM260 / TRAÇADOS

NC 0156



1 134 955

REAR STABILIZER BAR EYELET BUSHING AND SHACKLE
B270F / B290F / VM270

NC 0157



82 074 379

FRONT STABILIZER BAR SLEEVE 40MM HOLE
B270F / B290F / VM270

NC 0158



20 500 857

FRONT STABILIZER BAR BUSHING VM240 /
VM260 / TRAÇADOS

NC 0163A



FRONT SHOCK ABSORBER BUSHING 20MM HOLE
B270F / B290F / VM270

NC 0161



205 530 83

FRONT SHOCK ABSORBER BUSHING 20MM HOLE
VM240 / VM260 /
TRAÇADOS



NC 0167



3 090 957

FRONT SPRING EYELET
BUSHING 20MM HOLE
B270F / B290F / VM270

NC 0167A



3 091 744

UPPER / LOWER REAR SHOCK
ABSORBER NEEDLE BUSHING
FH / FH12 / FM9 / B10M /
B58E / B9R

NC 0212



3 028 448

FRONT AND REAR STABILIZER
BAR BUSHING
B10M / B12 / FL608 / B270F /
B290R



NC 0046



6 007 014 058 00 3

REAR STABILIZER BAR
BUSHING
A-6 / A8 / W8

NC 0047



6 007 014 058 00 3

REAR SHOCK ABSORBER
BUSHING
A-6 / A8 / W8

NC 0048



6 007 014 008 00 6

FRONT STABILIZER BAR BUSHING
OR LINK ROD
A-6 / VOLARE W8

NC 0049



6 007 014 079 00 7

FRONT SHOCK
ABSORBER BUSHING
(INTERNAL 12MM)
A-6 / A8 / W8

NC 0049A



FRONT SHOCK
ABSORBER BUSHING
(INTERNAL 14MM)
MA12 / MA15

NC 0163



FRONT SHOCK
ABSORBER BUSHING
(INTERNAL 20MM)
MA12 / MA15

NC 0051



6 008 014 701 00 4

LARGER HOLE STABILIZER
BAR SLEEVE
A-6 / A8 / W8

NC 0010



6 010 014 025 00 4

FRONT STABILIZER
BAR BUSHING
MA12 / MA15

NC 0079A



6 012 014 009 00 4

FRONT STABILIZER BAR
EYELET BUSHING
MA12

NC 0042A



6 007 014 042 00 5

FRONT / REAR SPRING
BUSHING
A-6 / A8 / W8

NC 0068



SQUARE ANTI-NOISE PAD
VOLARE W8



NC 0050



6 007 014 042 00 5

VOLARE REAR SPRING
SHACKLE BUSHING
A-6 / A8 / W8



TOYOTA

NC 0204



6 007 014 079 00 7

CONICAL BIPARTITE SHOCK
ABSORBER BUSHING FOR
TOYOTA BANDEIRANTES
TOYOTA BANDEIRANTES

NC 0024A



488 175 010

PAIR OF REINFORCED
FRONT LINK RODS
YARES / ETIOS - ALL

FIAT IVECO

NC 0057



504 112 267

REAR SPRING BUSHING FOR
REAR (LENGTH 70MM)
IVECO DAILY

NC 0020



580 130 7651

IVECO VERTIS SPRING
BUSHING 20MM HOLE
LENGTH 95MM
IVECO VERTIS

NC 0021



984 1393

IVECO VERTIS SPRING BUSHING
20MM HOLE LENGTH 85MM
IVECO VERTIS

NC 0022



5 949 896 230

IVECO VERTIS SPRING
BUSHING 20MM HOLE
LENGTH 90MM THIN
IVECO VERTIS

NC 0023



580 237 4371

FRONT AND REAR STABILIZER
BAR EYELET BUSHING
18MM HOLE
IVECO VERTIS

NC 0073



130 464 1080

SMALLER REAR SPRING
EYELET BUSHING
DUCATO



NC 0070



93808935

SMALLER REAR SPRING
EYELET BUSHING
IVECO DAILY



NC 0072



130 464 0080

SMALLER REAR SPRING
EYELET BUSHING
DUCATO





HYUNDAI

NC 0060



LOWER SPRING BUSHING
(SMALLER)
H100 / HR

NC 0078



REAR SPRING BUSHING
FOR FRONT H100
H100 / HR

NC 0061



544 224 30 00

UPPER SPRING BUSHING
(LARGER)
H100 / HR

NC 0127



H5 471 943 001

PAIR OF FRONT LINK RODS
HYUNDAI HR



NC 0038A



600 511 413A

REAR LINK ROD FOR FORD
FOCUS 2009 TO 2013
FOCUS

NC 0079



T21 411 045

FRONT STABILIZER
BAR BUSHING
**16180 / 16210 / 17210 /
17240**

NC 0094



2SL 411 071

FRONT STABILIZER BAR LINK
BUSHING KIT **16180 / 16210 /
17210 / 17240**

NC 0094A



2SL 411 071

MALE FRONT STABILIZER
BAR LINK BUSHING **16180 /
16210 / 17210 / 17240**

NC 0094B



T06 513 441

FEMALE FRONT STABILIZER
BAR LINK BUSHING **16180 /
16210 / 17210 / 17240**

NC 0120



TAR 411 041

FRONT STABILIZER
BAR SLEEVE
16180 / 16210 / 17210 / 17240

NC 0024A



BTC 08206

PAIR OF REINFORCED
REAR LINK RODS
FORD FOCUS 2003 A 2012



SCANIA

NC 0101



1 153 287

PAIR OF UPPER SHOCK
ABSORBER ROD BUSHINGS
K112 / K113

NC 0146A



1 429 110

FRONT/REAR STABILIZER
BAR EYELET BUSHING
16MM HOLE
F112 / F113 / F113HL

NC 0146



1 516 496

FRONT STABILIZER BAR LINK
ROD BUSHING KIT
F94 / K114 / K124 / K310

NC 0150



600 511 413A

REAR STABILIZER BAR EYELET
BUSHING 20MM HOLE
K124

NC 0163A



1 677 867

FRONT/REAR SHOCK
ABSORBER BUSHING
F112 / 113 / L113 / K113



NC 0034



94 745 091

UPPER CONTROL ARM
BUSHING FOR GM
**S10 / TRAILBLAZER 2013
OR UP**

NC 0035



94 745 094

LOWER CONTROL ARM
BUSHING FOR GM
**S10 / TRAILBLAZER 2013
OR UP**

NC 0024



F57A 3A262 CA

PAIR OF REINFORCED
LINK RODS
GM S10 / BLAZER 97 / 2014

RANDON[®]
IMPLEMENTOS

NC 0062



R71000004

TRAILER TIE ROD
CONICAL BUSHING
RANDON ULTRALIGHT

NC 0142



208 006 277

RANDON 2000
TRAILER BUSHING
RANDON 2000

NC 0122A



429 834 972

TRAILER SHOCK
ABSORBER BUSHING
RANDON



RENAULT

NC 0036



0036 8200 723 745

FRONT LINK ROD FOR
RENAULT SANDERO
LOGAN CLIO
SANDERO / LOGAN / CLIO

NC 0206



8200 024 453

SMALLER REAR SPRING
EYELET BUSHING
MASTER



NC 0217



8200 024 454

LARGER REAR SPRING
EYELET BUSHING
MASTER



NC 0214A



BTC 22 116

PAIR OF REINFORCED
FRONT LINK RODS
JAC J2



FOR US, YOUR TIME IS PRECIOUS

- ✓ More stability
- ✓ Less time in replacement
- ✓ Smooth and safe driving
- ✓ Proven durability
- ✓ Tire savings
- ✓ Resistant to oil, solvents, and saltwater

UP TO 5X

**STRONGER
THAN RUBBER!**

☎ (11) 2912-7778

📞 (11) 96637-5488

✉ comercial@timeparts.ind.br

🌐 www.timeparts.ind.br

📷 @timeparts

📘 timeparts

1014B Antennas Street - Vila Califórnia, São Paulo | Zip Code 03213-000